



Tote Solutions Ltd.

Winder Assembly

To aid in dispensing all your product from the liner below are instructions on how to use the winder assembly with a form-fit liner in a LiquiFold 315 container.



- Tote is ready for dispense.



- Place winder across the top of the LiquiFold 315 and the opposite side of the bottom discharge.



- Before dispensing, start winding the top of the liner into winder.





- As liner dispenses, continue to wind liner into winder and move toward dispense fitment.



- Continue winding pass fill fitment until liner is fully dispensed.



- Liner is fully dispensed.

