

Liquifold Dispensing

– emptying by using external valve –



1. Remove the tamper evidence cap
2. Remove the cap from the gland
3. Use a valve with either a crown cutter or a knife attached to it
4. Attach the valve tightly to the gland
5. Remove the outer cap from valve and connect discharge hose
6. Start emptying
7. After emptying - replace cap
8. Release gland from the Liquifold

